







Important Safety Information

- Only operate garage door when in full view.
- Keep hands and other body parts away from a moving garage door
- Do not allow children to play with or near a garage door.

Cleaning Your Gliderol Garage Door

Caution: Never use abrasive or solvent type cleaners like turpentine, petrol, kerosene or paint thinners to clean door surfaces as it may ruin the finish.

Gliderol Colorbond® & Timber Doors

To maintain smooth operation, an attractive finish, and to enhance the life of your Gliderol door, regularly wash the curtain with a sponge, soft cloth or soft bristle nylon brush and fresh, clean water. If this method does not remove all the dirt from the surface you may use a mild solution of pure soap or non-abrasive kitchen detergent and warm water. Please ensure you rinse the surface thoroughly, with clean water, to ensure all detergent is removed.

If the sealer on your timber door appears dull or starts to peel, a refresher coat will keep the timber protected and the door looking like new. Any door that has been exposed to severe weather such as hail needs to be resealed immediately.

Gliderol Custom Finish Doors

(Aluminium, Polycarb/Acrylic Inserts etc)

To maintain and enhance the life of your Gliderol custom finish door regularly wash the curtain with fresh, clean water. If this method does not remove all the dirt from the surface use any non-corrosive/non-abrasive polycarbonate acrylic cleaner.

Maintaining Your Gliderol Garage Door

Regular maintenance of your Gliderol Garage Door is necessary for smooth performance, good functionality and increasing the life of your door.

Remember defective garage doors can represent a serious hazard. Regular door maintenance helps to prevent accidents and avoid unnecessary service bills.

Caution (Roller Doors Only): Never use oil or petroleum-based lubricant including grease for maintaining your garage door as it may deposit dust particles in guide tracks and damage door operation.

Visually Inspecting & Maintaining Your Residential Gliderol Roller & Panel/Sectional Door

Conduct a visual inspection of mounting brackets, springs, tracks, guide lugs, fasteners, drive unit cables, weatherseals, etc. for any wear and tear at least once every six months.

Roller Doors Only: Lubricate springs, moving parts, guide tracks and hinges twice a year, or as required, with silicone based lubricant only.

Panel Doors Only: Panel Doors need oiling every 3-6 months and servicing every 2 years (more often for coastal properties). Motor oil (in an oiling can), RP7 or WD40 are all suitable for use. Apply oil to hinges, springs and wheel bearings only (refer owner's manual). It is not necessary to spray the chain unless it appears to be rusted. In this instance apply oil sparingly and wipe off any excess with a rag.

Gliderol Garage Door Balance Testing

Your Gliderol garage door should be perfectly balanced for optimum performance and power consumption (for electric operation). Perform a door balance test at least once every six months to increase the efficiency of your door:

- 1. Fully close the door.
- 2. If the door is operated electronically put it into manual operation (refer owner's manual).
- 3. Lift the door manually to waist height, say one metre above the floor level. You should be able to lift the door with little effort and the door should stay open at that position.
- 4. If the door does not stay at that position (one metre) this implies the door is out of balance. Get the door balanced by a Gliderol authorised service agent.

Gliderol Garage Door Auto Reverse Testing

Automatic garage doors should auto reverse when they detect an obstruction while closing. Conduct an auto reversing test at least once every six months to prevent accident and damages to motor and control unit:

- 1. Ensuring the door is properly balanced, as described above, fully open the door using handset.
- 2. Place a 20cm thick object, preferably wood, below the door.
- 3. Close the door when using a handset.
- 4. The door should auto reverse after striking the object (wood). If it doesn't, call a Gliderol authorised service agent to fix the problem.

If the door is fitted with additional safety devices like a photo electric beam sensor to prevent human entrapment please ensure it works properly.

